

Mohawk Finishing Products

A Division of RPM Wood Finishes Group, Inc.

Product Data Sheet

Deep Cleaner

M850-20164

8 fl. oz. bottle

Product Description: Deep Cleaner is a very strong cleaner for topcoated (pigmented) leathers. It performs a powerful cleaning action by removing all types of stains, including oily and greasy stains. It is very effective on jeans, newspaper, and dye transfers in particular.

Characteristics:

Physical state: Liquid

Package life: Maximum 1 year from date of manufacture, must be kept in original container.

Storage: Store in cool, dry place. Keep container closed when not in use.

HMIS:

Health: 2

Flammability: 1

Reactivity: 0

Personal Protection: B

Specifications:

Leather type usage: For topcoated leathers. Do not apply on nubuck, suede or aniline leathers.

Pre-test: Prior to use, pre-test the leather in an inconspicuous area to see if the leather is colorfast by dampening a white cloth with the Deep Cleaner and rubbing the leather very gently. If discoloring occurs, discontinue use unless you are prepared to apply Mohawk Top Coat. You may also need to apply Mohawk Pigment Touch-Up after using Deep Cleaner. Never rub this product aggressively because you will damage your leather.

Directions: It's always best to try cleaning the spot(s) with Leather Cleaner first because Leather Cleaner is very mild. If Leather Cleaner cannot remove the spot, use Deep Cleaner for deeper penetration and more powerful cleaning action. Use Deep Cleaner as follow: Shake well. Apply Deep Cleaner directly to a soft white cloth and gently rub over the soiled area with a circular motion – constantly checking the cloth for color transfer. If any color is transferred to the cloth, discontinue use unless you are prepared to apply Mohawk Top Coat and possibly Pigment Touch-Up a after using. Never rub aggressively. For heavy soiling, it may be necessary to repeat the process. After the spot is remove, clean the area again with Leather Cleaner to remove all residues of Deep Cleaner and then wipe with a wet sponge. Absorb the excess liquid with absorbent paper or a dry cloth then leave to dry. A household hair dryer may be use to speed up drying. If the leather remains sticky after cleaning and drying, apply Mohawk Top Coat to the affected area. Protect the leather with Leather Protector.

Routine care: Leather Cleaner should be part of a schedule of cleaning and protecting. For high use pieces like automotive seats, recliners, of family room furniture, cleaning is recommended monthly. For lesser-used pieces, full cleaning should be twice per year. A helpful tip is to use Leather Cleaner applied to a lint free cloth as part of your dusting routine to wipe off the leather furniture regularly. After a full cleaning, apply Leather Protector to renew the protection level.

Safety cautions: Use only in well ventilated area. Avoid contact with eyes, skin and clothing. Avoid breathing vapor. Additional local exhaust ventilation is recommended where mists or vapors may be released.

KEEP OUT OF REACH OF CHILDREN

MSDS: If Material Safety Data Sheet is required, contact:
Mohawk Finishing Products
Division of RPM Wood Finishes Group, Inc.
P O Box 22000
Hickory, NC 28603

Phone: 1-800-545-0047

Fax: 1-800-721-1545